

SLIDERPLUS


USER'S MANUAL

Before operating your edelkrone,
please watch the users manual video.

TABLE OF CONTENTS

1. WHAT'S IN THE BOX & THE BASICS.
2. MOUNTING YOUR SLIDERPLUS TO YOUR TRIPOD
3. MOUNTING YOUR CAMERA TO YOUR SLIDERPLUS
4. CAUTIONS & TIPS


1. WHAT'S IN THE BOX & THE BASICS



- 1/ SliderPLUS/PRO
- 2/ Pop up screw
- 3/ 3 mm allen wrench

- 4/ Tripod screw port
- 5/ Protection bar
- 6/ Feet knobs


2. MOUNTING YOUR SLIDERPLUS TO YOUR TRIPOD





1/ Detach tripod head 


2/ Put your SliderPLUS/PRO on top of your tripod and turn it clockwise until it's tight.

3. MOUNTING YOUR CAMERA TO YOUR SLIDERPLUS



- 1/ SliderPLUS has 3/8"-16 screw for your tripod head hidden inside. You can access this screw with the help of a coin. 
- 2/ Using a coin, turn the screw until it pops out. To lock the screw back again just press it down and turn it counter clockwise.
- 3/ Place your tripod head on the screw and turn it clockwise until it tightens.



 Detailed video explaining mounting your SliderPLUS to your tripod steps at the link: manuals.edelkrone.com

 Before operating your product, please watch the users manual videos from the link: manuals.edelkrone.com


4. CAUTIONS & TIPS

Please contact our dedicated customer care team for recommended tripod legs.


1. In order to get perfect results with your SliderPLUS/PRO please attach your SliderPLUS/PRO directly to the tripod legs.



2. If your tripod has a feature that allows you to extend the height from its neck, we suggest keeping it down and as tight as possible in order to prevent a rainbow effect.



3. Please be sure that your SliderPLUS/PRO withstands within the area of the tripod legs to prevent falls and balance issues. Always make sure that your system is leveled and balanced.



4. Always keep your slider locked while its not in use.

5. Use feet knobs to level your system.

6. SliderPLUS/PRO can travel twice it's own length when it's mounted on a tripod. While using it on its feet, it can only travel it's own length.

▶ Before operating your product, please watch the users manual videos from the link: manuals.edelkrone.com

▶ For more sliding tips please watch the users manual videos from the link: manuals.edelkrone.com

edelkrone cannot be held responsible for damage caused by improper use or modification of the product.



*For more information and tips about your SliderPLUS, please watch the user's manual videos at the link, **manuals.edelkrone.com***



